



Step 7) Place two reeds in center of reed cage, making sure they are at the bottom.



Step 8) Separate reeds and place new retaining bar (supplied) on an upward angle making sure it fits between the reeds.



Step 9) Now slide bar in parallel to reed cage base, making sure to engage reed locating tabs.



Step 10) Using a screwdriver or similar tool, push retainer bar flush with reed cage surface.



Step 11) Place reeds on outside surface and press on to locating tabs.



Step 12) With reeds in place, push reed cage through flange until locating tabs snap into their openings.